13. Using the HyperTerminal

BASIC OPERATIONS

1 Connect the serial output of the equipment to the serial output of the computer

2 Set the output of the equipment to PRINTER.

3 Open HyperTerminal (Start> All Programs> Accessories> Communications> HyperTerminal.) Or, click Start> Run and type hypertrm.exe.

4 Enter a description for the connection that will be created.

5 Select the communication port COM1*

6 Configure as per the screen below and click OK.

7 Put the equipment into read mode, the data will be automatically displayed in HyperTerminal and printed out if necessary.